

## Solvent Clean

### Procedure

#### Soak in:

1. Acetone, 5 min
2. Toluene, 5 min
3. Acetone, 5 min
4. Methanol, 5 min
5. Rinse in DI, 5 min
6. Blow dry in N<sub>2</sub>

### Notes

1. If sample conditions permit, use ultrasonic cleaner for each of the solvent steps. Certain samples with weakly bonded thin film coatings may suffer loss of adhesion and peeling.