

#### Quantum Dots: formation

**ECE 598XL** 

Fall 2009


#### Outline

- Introduction
- Self-organized QDs
  - Critical thickness
  - S-K growth mode
- Patterned QDs
  - Lateral positioning
  - Multistack ordering
- QDs in QWs
  - Case study: InGaN QDs in InGaN QW
- Anti dots

#### QD Based Device Applications

- QD infrared photodetectors (interband and intraband optical transitions)
- QD lasers and LEDs
  - Edge emitters
  - VCSELs
  - Photonic crystals
- QD solar cells
- Single QD as building blocks for
  - Quantum information processing
  - single electron devices
- Dislocation filter for metamorphic growth

#### Methods of Nanostructure Formation



D. Bimberg, M. Grundmann, N. Ledenstov, "Quantum Dot Heterostructures"

## Spontaneously Formed Nanostructures




Fig. 1.5. Examples of spontaneously formed nanostructures. (a) Periodically faceted surface. (b) Wires of a deposited material formed in the grooves of the periodically faceted surface. (c) Capped structure (b) forming quantum wires within a matrix. (d) Array of two-dimensional islands in submonolayer heteroepitaxy. (e) Capped structure (d) forming two-dimensional quantum dots embedded in a matrix. (f) Array of three-dimensional coherently strained islands over a wetting layer on a substrate surface. (g) Capped structure (f) forming an array of three-dimensional quantum dots embedded in a matrix

#### QD Formation Methods

- Self-organized QDs
  - Stranski-krastanov growth:
    - Lattice mismatch
    - Strain
  - -Growth methods:
    - MOCVD
    - MBE

- Patterned QDs
  - Lithography
  - Etching
  - -Growth
- Colloidal QDs
  - Reaction T, t
  - -Core-shell
  - Biological tag

#### Critical Layer Thickness

- <u>Pseudomorphic</u>: for thin layer where the overlayer is coherently strained (overlay adopt lattice constant of the substrate).
- <u>Dislocation formation</u>: for thick layers where the overlayer is relaxed (adopt its original lattice constant) through dislocation formation.
- <u>Critical layer thickness</u>: transition between the above two regions
  - Function of mismatch strain, etc.
  - Matthews-Blakeslee model (1970s)
  - Ge on Si (4%): 3-4 ML
  - InAs on GaAs (7.2%): 1.7 ML
  - InAs on porous GaAs: 4.2 ML

$$E_{strain} = \lambda \left(\frac{\Delta a}{a}\right)^2 At$$

 $\lambda = \text{elastic modulus}$ 


 $\Delta a =$  forced change in lattice constant


a ="free"lattice constant

A = area


t = thickness


## Critical Layer Thickness






### Three Modes of Epitaxial Growth






# Phase Diagram coverage H (ML) vs misfit strain ε




#### QDs – shape, size, size distribution

Substrate orientation dependence




STM of InAs/GaAs QDs grown by MBE on (100), (311)A and (311)B GaAs substrates.



#### Coverage vs QD Density

Density of 3D islands vs InAs coverage




B.A. Joyce, D.D. Vvedensky/Materials Science and Engineering R 46 (2004) 127–176

### QDs – shape, size, size distribution

- Ge QDs/Si(100):
  - Competition between surface energy and strain relaxation in the island bulk
    - Pyramids (high aspect ratio, square base with {105} facets): more surface energy but relaxes more strain
    - Domes (low aspect ratio, multi-faceted):
    - Change from pyramids to domes w size
- InAs/GaAs
  - Pyramid: bounded by four steep {137} facets

#### QDs – shape, size, size distribution

Growth conditions, size and composition dependence




#### Criteria for QD Growth


- Size controllability: size and uniformity
- Site controllability: positioning and density
- Vertical stacking and ordering

#### Lateral Positioning: patterned QDs


- Site control using preferential nucleation sites on a substrate
  - ex situ Lithography defined surface morphology
    - Maskless self strain management
      - Raised stripes and squares
      - Pits/holes (ebeam, nanoporous Al<sub>2</sub>O<sub>3</sub> template, diblock copolymer nanopatterning, etc.)
    - Masked (growth inhibition) selective area growth
      - Oxide
      - metal
  - Surface steps and bunches
  - Intentional formation of dislocations

### Lateral Positioning: patterned QDs






**Strain Management** 




# Patterned substrate with nano hole arrays




and Kivoshi Asakawa

#### Site-controlled InAs QDs

 PL wavelength tuning using strain reducing layer In<sub>0.2</sub>Ga<sub>0.8</sub>As (0 – 6 nm) on the InAs QDs



#### InAs QDs by Nano Jet Probe Patterning



## Linear alignment of GaN QDs on vicinal AlN/SiC substrate by controlled nucleation on steps

- Vicinal SiC substrate preparation
- Stepped AIN layer
  - Height and width of AIN step growth condition dependent




FIG. 4. AFM image of GaN quantum dots grown on a vicinal AIN~0001! surface. The upper inset gives the details of the 2D-FFT spectrum and the lower inset gives details of the center of the autocorrelation picture.




FIG. 1. AFM images of ~a! a 4H–SiC~0001! vicinal surface after HCl/H2 etching and ~b! a ;50 nm AlN layer grown on a 4H–SiC~0001! vicinal surface. The arrow on the images indicates the [11-20] direction.






FIG. 2. AFM image showing the preferential alignment of GaN QDs along the AIN bunched steps.

JAP 93, 3108, 2003

### QDs growth using anti-surfactant

- Anti-surfactant: to promote 3D growth
  - Tetraethylsilane Si(C2H5)4 (TESi)
  - Modifies surface energy







w/o TESi. No QDs

Appl. Phys. Lett. 69 (26), 23 December 1996


#### Selective Area Epitaxy Process Overview




#### Selective area growth and lateral overgrowth





### QDs at the Apex






#### **Oxide Patterned InGaAs QDs**






## InGaAs QDs by top-down e-beam patterning and wet etching using HSQ as mask



#### Multilayer Ordering: vertical positioning

- 3D arrays of QDs
- Self-assembly through strain management
- Alternating: GaAs/QD/GaAs/QD/GaAs
- Spacer layer
- Lateral strain inhomogeneity due to buried islands is transmitted to the surface through strain, so that nucleation of 3D islands in the 2<sup>nd</sup> and subsequent layers is no longer spatially random.

#### **Vertical Correlation: SiGe QDs on Si**



- Spacer layer thickness dependence
- Islands become larger w layer #
- Islands become more regular in shape
- Increase in size  $\propto 1/\text{density}$
- Wetting layer thickness decrease w layer #
- Solution: reduce Ge dose w layer #

### InGaAs QDs on GaAs: 50 periods




Fig. 4. AFM image of a 50-period undoped InGaAs (6.1 ML)/GaAs (20 nm) QD SL grown on {113}B GaAs substrate.


Fig. 5. <-110> pole bright-field TEM crosssection image of a 50-period undoped InGaAs (6.1 ML)/GaAs (20 nm) QD SL grown on {113}B GaAs substrate.

**NREL** 

## Composition Fluctuation in InGaN QW Blue LEDs


- Nominal quantum well structure:
  - $-\ln_{0.2}Ga_{0.8}N$  3nm well  $/\ln_{0.05}Ga_{0.95}N$  6 nm barrier


Localized energy states - QE



(b)


- Compositional modulation due to phase separation to produce In-rich QDs
- High quantum efficiency of the system despite
   > 1e8 cm-3 dislocation density is attributed to deep localization of excitons in QDs






#### Antidots: tensile strained QDs

- Only compressively strained materials readily form self-organized QDs
- Tensile strained QDs can only be formed under extreme non-equilibrium conditions
  - 0.06 (GaAs), 0.04 (AlAs)and 0.25 (InAs) ML/s
- Applications
  - Not fully confined e-/h<sup>+</sup>
     states
  - Yes confined optical phonon (phonon dots)





#### Summary

- Bottom-up self-organized QD formation
  - Critical thickness
  - S-K growth mode and coherently strained QDs
  - Energy minimization: size, shape, distribution
- Top-down patterned QD formation
  - Lithography defined growth template
    - Non-planar structure
    - Selective Area Epitaxy (SAE) or SAG
- Multi-stack QDs
- Composition modulation
- Anti-dots or nanopores